

Quick Start Guide

Thank you for purchasing the RCA Digital Voice Recorder (RP5130). In this Quick Start Guide, you will learn how to set up the date and time for your player and access the folders/player menu.

Date and time setup

1. Insert 2 AAA batteries in the player.
2. When **YEAR** shows, press **◀▶** or **VOLUME +/-** to adjust the value (default year: 2008) and then press **MENU** to confirm.
3. Repeat step 2 to set the "Month", "Date", "12/24 hour time", "Hour" and "Minute"
4. After the date and time are set, press **▶ PLAY** to turn on the player and start using.


Accessing folders/player menu

Accessing folders

Press **MENU** repeatedly to select folders (1-6 and ).

Accessing player menu

1. Press and hold **MENU** for about 2 seconds and then release the button. The first menu item, **DICT** or **CONF** flashes on display.
2. Then press **MENU** repeatedly to select another menu items. Refer to the user manual for more information.



For details on operating the player, please refer to the user manual.



Guía de Inicio Rápido

Gracias por comprar la Grabadora de Voz Digital RCA (RP5130). En esta Guía de Inicio Rápido, usted aprenderá cómo configurar la fecha y hora para su reproductor y acceder el menú carpetas/reproductor.

Configuración de fecha y hora

1. Inserte 2 baterías AAA en el reproductor.
2. Cuando se muestre *YEAR*, presione **◀▶** o **VOLUME +/-** para ajustar el valor (año predeterminado: 2008) y luego presione **MENU** para confirmar.
3. Repita el paso 2 para configurar el "Mes", "Fecha", "12/24 tiempo en horas", "Hora" y "Minuto"
4. Después de que la fecha y hora estén establecidos, presione **▶** **PLAY** para encender el reproductor y comenzar a usarlo.

Para acceder el menú carpetas/reproductor

Para acceder carpetas

Presione **MENU** repetidamente para seleccionar carpetas (1-6 y ).

Para acceder el menú reproductor

1. Presione y sostenga **MENU** por unos 2 segundos y luego libere el botón. El primer elemento de menú, *DICT* o *CONF* parpadea en la pantalla.
2. Luego presione **MENU** repetidamente para seleccionar otros elementos del menú. Refiérase el manual del usuario para más información.



Para detalles sobre operación del reproductor, por favor refiérase al manual del usuario.

